LAMP。ステンレス鋼製 引戸掘込カマ錠HC-30L ステンレス鋼製 引戸掘込力マ錠HC-30HL(表示器付き)

このたびは、弊社製品をお買い上げいただき、誠にありがとうございます。 取り付け作業に当っては本書を良くお読みのうえ、正しく取り付けていただく ようお願いいたします。

取り付け後は、必ずお使いになる方が本書を保管してください。


⚠ 注意

・加工寸法は必ずお守りください。誤った加工寸法で無理な取り付けを行うと、 本来の性能を発揮できない恐れがあります。

■部品構成


内容物に間違いがないことを確認してください。

本品は左右勝手兼用です。



■切欠加工図

下図を参考に、加工穴のセンターラインおよび上下の中心が一致するよう切欠加工を行ってください。



■取り付け手順

①ケース錠の取り付け


ケース錠を引戸に取付用木ねじ(3.5×20)で取り 付けます。 ケース錠 取付用木ねじ (3.5×20) カマがケース錠 の中に収納され ていることを確 認してください。 ※カマが出ている場合は、角芯棒を ケース錠の角穴に差し込み、トリガ を指で押しながら、角心棒を回転

②サムターン、角芯棒の取り付け サムターンの角穴に角芯棒を差し込 みます。取り付けた角芯棒をケース 錠の角穴に差し込み、サムターンを 取り付けてください。(この時、サム ターンのレバーは垂直にしてくださ サムターン 引戸室内側 角芯棒 サムターン 角穴


③表示器、間仕切の取り付け

室外側より表示器または間仕切の角穴に角芯棒を 差し込みます。(表示器は窓を青色に合わせてくだ さい。)サムターン側より本体組立用ねじで取り付 けます。

させてカマを収納してください。




④受座, 受座プレートの取り付け 枠に受座、受座プレートを取付用木ねじ(3.5×20)で 取り付けます。



■動きの確認

- トリガーを指で押しながらサムターンのレバーを矢印の方向に90°回転させてください。 スムーズにカマが出れば正常です。
- HC-30HL(表示器付)は、表示器の窓の色が青→赤に変わることを確認してください。 表示器の窓の青が解錠状態、赤は施錠状態を示します。 表示が逆転している場合は、取り付け手順の③に戻って取り付け直してください。



本製品に関するご質問・ご相談は、お買い求めいただいた販売店、または下記の窓口にお願いいたします。

アーキテクトサポート室 電話番号 03 (3864) 1122 受付時間 **月~金 9:00~17:30** (年末・年始・夏季休暇等は除く)

> FAX 03(3863)6875 E-mail: support@sugatsune.co.jp 東京都千代田区岩本町2-5-10 〒101-0032



ISO 9001(JSA0384) · ISO14001(JSAF597) 寒春營約 ※ISO9001:国内各拠点 ※ISO14001:千葉事業部 千葉工場 および 物流事業部 物流センタ http://www.sugatsune.co.jp/

Sliding Door Latch, Model HC-30L Model HC-30HL (with indicator)

Installation Manual

For safe and correct operation of the products, read this manual carefully and follow the direction given in it to correctly install it.

⚠ After the product is installed, hand this manual over to the user, who should keep it for later consultation.

■ Parts composition Check that the package contains each items correctly. Screw for mounting the main body of the latch (See Note 1) Note 1: Three sizes of mounting screws are included. Select a proper size Spindle (See Note 2) of screw to fit the thickness of Indicator your door. (HC-30HL only) ·For door thickness 28~32 mm: Latch body Screw length 22mm ·For door thickness 33~36 mm: Screw length 27mm ·For door thickness 37~40 mm: Screw length 32mm Note 2: Three lengths of Spindle are Trigger included. Select a proper length of **Emergency Release** Spindle to fit the thickness of your (HC-30L only) ·For door thickness 28~31 mm: Screw length 23mm Wooden screw ·For door thickness 32~36 mm: (3.5×20) Screw length 27mm

Strike plate

■ Drawing for notch working


Refer the below drawings for your notch working correctly.

Strike and Strike plate (Sash side)

·For door thickness 37~40 mm:

Screw length 32mm

Latch body (Sliding door side)



■ Installing procedures

① Mounting Latch body

Mount Latch body onto the sliding door with Wooden screws (3.5 x 20).


Latch body

Wooden screw (3.5 x 20)

Check that Hook is set inside Latch body.


**Should Hook be out of Latch body, insert Spindle into the square hole of Latch body, unsert Spindle into the square hole of Latch body, insert Spindle, and push Hook into Latch

② Mounting Thumb turn and Spindle Insert Spindle into the square hole of Thumb turn. Then, insert the pin into the square hole of Latch body to mount Thumb turn itself on Latch body. (Keep the knob of Thumb turn at vertical position.)




3 Mounting Indicator / Emergency Release Insert Spindle into Indicator or Emergency Release

from outside (Set the color of Indicator to "blue"). Fix Indicator or Emergency Release using mounting. screws



4 Strike and Strike plate


Set the seat and the plate into the notched hole of door sash with Wooden screws (3.5 x 20).




■ Checking the operation of Latch

•Turn the knob of Thumb turn 90° in the direction of ARROW showing, while depressing Trigger with your finger. If Hook comes out smoothly, you have installed Sliding door latch correctly.

·In case of model HC-30HL (type with Indicator), make sure the color of Indicator changes from "blue" to "red", or vice versa. Indicator "blue" shows an unlatched status and Indicator "red" shows an latched status. If the showing color does not meet this manual specification, return to Step 以 and mount Indicator again.





SUGATSUNE KOGYO CO.,LTD. Phone: +81 3 3866 2260

F a x : +81 3 3866 4447 E-mail: export@sugatsune.co.jp Website: www.sugatsune-intl.com SUGATSUNE KOGYO (UK) LTD. Phone: +44 118 9272 955

F a x: +44 118 9272 871 E-mail: sales@sugatsune.co.uk Website: www.sugatsune.co.uk SUGATSUNE AMERICA, INC. Phone: +1 310 329 6373 F a x : +1 310 329 0819 E-mail: sales@sugatsune.com Website: www.sugatsune.com SUGATSUNE SHANGHAI CO., LTD. Phone: +86 21 3632 1858

F a x : +86 21 3632 1868 E-mail: lamp@sugatsune.com.cn Website: www.sugatsune.com.cn

ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.