
# LAMP. HG-VH8 Variety Hinge Installation Instructions Designies.



Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

## **ABOUT THE PRODUCT**

- Hinges for light weight lids, doors.
- Various motions in the same appearance
- Various combinations such as self-opening hinge + damper hinge (refer to "Possible combinations")



#### **SPECIFICATIONS**

Order code	Part No.	ID stamp	Color	Part built in Torque cNm / piece		Operating temperature range	
170-032-616	HG-VH8-N-BL	N	Black			_	
170-032-617	HG-VH8-N-WT	I N	White	_	_		
170-032-618	HG-VH8-D3-BL	DO	Black	D	22~38		
170-032-619	HG-VH8-D3-WT	D3	White	Damper	2.2 ~ 3.8		
170-032-620	HG-VH8-OP-BL	OP	Black	Spring	* increase 1.53 cNm by 30 °	· ·	
170-032-621	HG-VH8-OP-WT	OF .	White	(self-opening)	of revolution		
170-032-622	HG-VH8-CL-BL	CL	Black	Spring	* increase 1.53 cNm by 30 °	0 ~ 40°C	
170-032-623	HG-VH8-CL-WT	CL	White	(self-closing)	of revolution	0 ~ 40°C	
170-032-624	HG-VH8-T15-BL	T1	Black	T	15+5		
170-032-625	HG-VH8-T15-WT	''	White	Torque	10±0		
170-032-626	HG-VH8-T35-BL	Т3	Black	Torque	35+10	1	
170-032-627	HG-VH8-T35-WT	13	White	Torque	30±10		


<sup>\*</sup> See "How to adjust spring torque" on the right page.

#### Possible combinations

Type of hinges	ID stamp	N	D3	OP	CL	T1	T3
Normal	N	0	0	0	0	0	0
Damper	D3	0	0	0	0	_	_
Spring (self-opening)	OP	0	0	0	-	Δ	Δ
Spring (self-closing)	CL	0	0	-	0	Δ	Δ
Torque	T1	0	_	Δ	Δ	0	0
Torque	T3	0	ı	Δ	Δ	0	0

Δ Please carry out thorough tests before using since performance with these combinations might vary depending on door size and weight.

# **MAXIMUM LID TORQUE CALCULATION**



(Calculation example)

When D=12cm, A=0.1cm, B=0.65cm, t=0.5cm, m=0.08kg

 $L = \sqrt{(12/2+0.1)^2 + (0.5/2+0.65)^2} = 6.13 \text{ cm}$ 

 $T = 0.08 \times 9.8 \times 6.13 = 4.8 \text{ cN} \cdot \text{m}$ 

### T=mx9.8xL

T: Maximum lid torque (Nm)

m: Lid weight (kg)

D: Lid length (m)


X=D/2+A Y=t/2+B


L: Distance between rotation center and gravity center of lid

$$L=\sqrt{X^2+Y^2}$$

# **DIMENSION**

Recommended screw: Bind head machine screw M3





## FOR YOUR SAFETY WORK AND OPERATION

This symbol denotes prohibited actions.

This symbol denotes what must be done.

Cautions: If these cautions are not followed, it may result in injury or damage.

This product is for indoor use only. Do not use outside or anywhere where it will be exposed to water.


① Do not use lubricant on the hinges since it may damages the hinges.


Align the shaft center of the hinges.

Use within the specified torque range. (Damper hinges and torque hinges)

# How to adjust spring torque (Spring hinges only)

Note that the direction to increase the spring torque for Self-open is different from the direction for Self-closing type.






#### Self-opening

# 2 Turn 30 1) Push until the clutch teeth are detached (3) Pull out

Check if the lid or door opens smoothly when it is released. If opening force is not enough, repeat step (1) to (3).

The torque increases 1.53cN m by every 30 ° of turn. The increasing limit is up to 4 turns (120 °). If you like to decrease the torque, turn the hex key to the opposite direction.

#### Self-closing



Check if the lid or door closes smoothly when it is released. If closing force is not enough, repeat step (1) to (3).

The torque increases 1.53cN m by every 30 ° of turn. The increasing limit is up to 4 turns (120 °). If you like to decrease the torque, turn the hex key to the opposite direction.



Before turning the hex key, make sure to push it enough so that the clutch teeth is released.

SUGATSUNE KOGYO CO.,LTD. Phone: +81 3 3866 2260

F a x : +81 3 3866 4447 E-mail: export@sugatsune.co.jp Website: www.sugatsune-intl.com

SUGATSUNE KOGYO (UK) LTD. Phone: +44 118 9272 955 F a x : +44 118 9272 871

E-mail: sales@sugatsune.co.uk Website: www.sugatsune.co.uk

SUGATSUNE AMERICA, INC.

Phone: +1 310 329 6373 F a x : +1 310 329 0819 E-mail: sales@sugatsune.com Website: www.sugatsune.com

SUGATSUNE SHANGHAI CO., LTD.

Phone: +86 21 3632 1858 F a x : +86 21 3632 1868 E-mail: lamp@sugatsune.com.cn Website: www.sugatsune.com.cn