## SOFT DOWN STAY NSDX-35/35E L/R INSTALLATION INSTRUCT



- Please read this instruction sheet carefully for proper installation and operation. Incorrect installation and improper use of the product may damage the unit or cause injury.
- This stay is designed for furniture or lightweight door and is equipped with a damping function.
- Sugatsune guarantees the quality of this product as for all its parts. It cannot however guarantee the final assembly as a whole.
- This product was manufactured and delivered with our utmost care. Should you however find any defect, please contact your dealer immediately.
- Sugatsune warrants that this product is free from defect for a period of one (1) year from the date of delivery.
- Sugatsune liability is limited to the replacement of this product by a similar one free of defect. In no case does this extend to the replacement of the installation or the cabinet as a whole.
- Please keep these instructions at hand for future use.
- Sugatsune cannot be held liable for any damage or injury caused by improper use or one different than the one this product was designed for.

## ⚠ CAUTIONS Any failure to observe the following precautions may result in personal injury or damage to the cabinet

- Make sure that installation position and specifications are followed. Unsuitable installation position may damage the mechanism when in case two stays are used together.
- Make sure that the arm of the stay is parallel with the side panel of the cabinet.
- Please avoid forced opening beyond the opening angle, and using excessive force while closing the door.
- This product is designed to operate at room temperatures between 0°C to 40°C (32F-104F).
- This product has a spring at the elbow section. Please be careful not to get your fingers caught in elbow section while you are handling the unit.
- Performance of hardware will be affected by unique factors in each application. Hardware must be tested in intended application to confirm the function.
- It is necessary to periodically check the fixing screws for loosing. Tighten the loosed screws as required.
- Do not force the door to close faster. It can cause damage to the product or hinge(s). Please make sure to check the operation after installation.

## ■ Model (For standard screw)


= model (i oi olamadi a oolom)				
Item No.	Position	Suitable screw on stay	Suitable screw on mounting plate	
NSDX-35L	Left	φ3.5×3	φ3.5×3	
NSDX-35R	Right	φ3.5×3	φ3.5×3	


### Model (For Furo screw)

=					
Item No.	Position	Suitable screw on stay	Suitable screw on mounting plate		
NSDX-35EL	Left	φ6.2×2 φ3.5×1	φ3.5×3		
NSDX-35ER	Right	φ6.2×2 φ3.5×1	φ3.5×3		

<sup>\*\</sup>psi 6.2 Euro Screw to be applied









## height (mm) 600 500 Door h 400 300 100 200 300 400 500 600 700 800 900 1000 1100 1200 1300 1400 1500 1600 Door width (mm)

\*In case of usual wooden flap of 20 mm thickness (specific gravity approx. 0.5)

Door height

Door thickness (20mm)

## APPLICABLE DOOR WEIGHT AND SIZE

This product must be applied to a door with specific weight and size. Lined Section on the right of the graph indicates applicable door weight range based on 1 unit per door.

Note-1: In case of 2 units (right & left) per door are used

Door Width can be twice as large, if the door height remains unchanged

Note-2: In case of different door thickness or specific gravity, door weight must fit with following formula.

\*1 unit per door MIN. - MAX.

1/2 door height[m]  $\times$  door weight[kg]  $\times$  9.8 = 1.96 - 6.86[N · m](20 - 70[kgf · cm]) (1/2 door height[inch] × door weight[lb] = 17 - 60[lb · inch])

\*2 units (right & left) per door: MIN. - MAX.

900

800

700

Center of gravity (Density = 0.5)

 $1/2 \text{ door height[m]} \times \text{door weight[kg]} \times 9.8 = 3.92 - 13.72[\text{N} \cdot \text{m}] (40 - 140[\text{kgf} \cdot \text{cm}])$  $(1/2 \text{ door height [inch]} \times \text{door weight [lb]} = 35 - 120[lb \cdot inch])$ 

Above drawing shows for NSDX-35L (left hand side mounting) and NSDX-35R (Right hand side mounting) symmetrically. Same mounting position is to be applied to the model of 35 EURO (type with EURO screw). Make a preparatory hole, Before drilling a \$\.06.2\$ EURO screw.

## NSDX-35 INSTALLATION PROCEDURE

- 1. Mount the body and arm fixing plate on sideboard and back of door with tapping screws (\$\phi 3.5) to oval holes temporarily.
- 2. Align notch on mounting plate and hole on arm by rotating the stays to fix them.
- 3. Check the function and adjust mounting plate on oval holes. Then fix them with the tapping screws in the round holes of the stay and mounting plate.

## NSDX-35E INSTALLATION PROCEDURE


- 1. Mount the stay on sideboard by applying EURO screw ( $\phi$ 6.2) to the larger round holes on the body.
- 2. Mount the arm fixing plate on back of door with tapping screws (\$3.5) to the oval holes temporarily
- 3. Align notch on mounting plate and hole on arm by rotating the body to fix them.
- 4. Check the function and adjust mounting plate on oval holes. Then fix them with the tapping screws in the round holes of the body and mounting plate.
- \*The side board must be strong enough for NSDX installation.

Mounting plates are available both in standard and clip type. When using a standard mounting plate type, be sure to fix it securely with supplied truss screw after installing the stay. When using a clip mounting plate type, be sure to insert arm completely.


SPEED ADJUSTMENT


In using a clip mounting plate type, be careful not to hit the arm or apply excessive force, as it may cause the arm to fall off and cause unexpected injury.


### **■CONCEALED HINGE** MEASURE PENING В C 80° 106 105-S 121-S 909 98 97-S 113-S 100° 92.5 | 91.5-S | 107.5-S **■PIANO HINGE OR BATT HINGE** Α D Ε 80° 100 99 115













## SPEED ADJUSTMENT SCREW

FASTER SLOWER

## 

Do not turn the speed adjustment screw exceeding the limit.

the speed adjustment screws on both sides must be turned evenly.

SUGATSUNE KOGYO CO.,LTD. Tokyo, JAPAN Phone: +81 (0)3 3866 2260 E-mail: export@sugatsune.co.jp SUGATSUNE KOGYO (UK) LTD.

Reading,UK Phone: +44 118 9272 955 E-mail: sales@sugatsune.co.uk

# SUGATSUNE EUROPE GmbH Düsseldorf, GERMANY

Phone: +49 211 53812900 E-mail: info@sugatsune.eu

Upon completion of installation, make sure the door opens and closes properly. To adjust the closing speed of door, turn speed adjustment screw. In case 2 units (right & left) are used on a single door,

> SUGATSUNE KOGYO INDIA PRIVATE LIMITED Mumbai, INDIA Phone: +91 22 28314490/91 E-mail: sales@sugatsune.in

# SUGATSUNE SHANGHAI Co., LTD. Shanghai, CHINA Phone: +86 21 3632 1858 E-mail: lamp@sugatsune.com.cn

## Guangzhou, CHINA

Phone: +86 20 6639 3552 E-mail: lamp@sugatsune.com.cn

# SUGATSUNE AMERICA, INC. California, USA Phone: +1 310 329 6373

E-mail: sales@sugatsune.com

Phone: +1 312 461 1081 E-mail: chicagoshowroom@sugatsune.com